

Honey Moisture Meter



Automatic Calibration & Automatic Temperature Compensation Functions are built-in. Therefore, you don't need to do the calibration every time when you measure. All you have to do is just push "Measure" button with your finger.

FEATURES

1. Measuring by micro-computer.
2. Easy to use, quick to read & compact.
3. Large Digital LCD displays.
4. Low battery sign appears.
5. Measuring up to 40%.

SPECIFICATIONS

1. Measuring Ranges	12.0% ~ 40.0%
2. Accuracy	±0.2%
3. Resolution	0.1%
4. Power Source	9V Battery x 1EA
5. Display	Large Digital LCD
6. Temperature Compensation	Automatic
7. Dimensions	154(L) x 108(W) x 43(H)mm
8. Gross Weight	Approx. 1Kg

Honey Moisture Meter (GMK-315AC)

1. The names of each part



GMK-315AC

2. Before Measurement

- Place a 9V battery into the battery compartment in the bottom of the instrument.
- If [CAL] sign appears and disappears on LCD, the instrument is ready to measure. (Automatic Calibration)
- Clean 'Sample Well' with water & tissue.


3. Measurement

- Drip a few drops of test sample on 'Sample Well'.
- Cover 'Sample Well' with 'Light Cover' outdoors (but not indoors), and press 'Measure' button.
- After [---] sign flickers a few times, measurement result appears on LCD in about 2 sec.

[Notice]

When the test sample is out of measuring ranges, [Err] sign appears.

4. Power

- The instrument switches off automatically about 1 ~ 2 min. later when there is no other operation.
- When [] displays, please change batteries.

5. Battery

- ▲ In case of no use for a while, please remove batteries.

6. Keeping

- Keep the instrument in a cool place.
- Clean the instrument after measurement.

7. Warranty

- The manufacturer grants 12 months of warranty since the date of purchase.
- In case of wrong use, abuse or misuse, warranty is not granted.

ACCESSORIES



Battery Remover



Light Cover



Carrying Bag